

Low Flow Air Atomizing

The XA nozzle system uses the energy in compressed air to produce highly atomized sprays at low flow rates. There are many interchangeable components that can be assembled to achieve a variety of spraying objectives.

SPRAY SET-UPS

XA nozzles produce eight distinctly different types of sprays, depending on which interchangeable air and fluid caps are selected. The spray type and flow rate are determined by the "set-up"—a specific combination of one air cap and one fluid cap.

Internal Mix Set-ups

Liquid and air streams meet within the nozzle and are mixed together and expelled through the same orifice(s). This internal mixing means the streams are not independent; a change in air flow will affect the liquid flow. This makes precise metering of the liquid more difficult than with an External Mix Set-up. Internal Mix Setups are able to produce the finest atomization of any of the XA set-ups, but they are generally not suitable for use with liquids which have a viscosity that is above 200 centipoise.




AIR FEED

LIQUID FEED

ANNULAR AREA

combined and mixed outside of the nozzle. Because there is no connection between the air and liquid lines within the nozzle, the air and liquid flow rates can be controlled independently, allowing precise metering of the liquid. The atomization can be controlled by adjusting the air flow rate—more air produces finer atomization. In most



cases these set-ups do not atomize as

External Mix Set-ups may be used

with liquids having a viscosity above

finely as Internal Mix Set-ups.

200 centipoise and for abrasive

suspensions. BETE Applications

Engineers can provide guidance for

AIR FEED

Siphon Set-ups

AIR ORIFICES

Internal and External Mix Set-ups require the liquid to be supplied to the nozzle under pressure from a municipal water supply, pump, or pressure pot. Siphon Set-ups use the flow of compressed air within the nozzle to siphon liquid from a container. Siphon Set-ups are frequently used for spraying additives from a container without the use of a pump. They provide the



Bold letters (A, B, C, D, E, F) refer to hardware assemblies



A. End Plug



1800 NOZZLE | +61 (3) 9583 2368

lowest flow rates available in the XA series (as low as 0.38 L/hr). They are generally not suitable for use with liquids having a viscosity above 200 centipoise.

By supplying the liquid under pressure, SR Set-ups may be used with liquids having a viscosity above 200 centipoise. In this case, the liquid flow rate is regulated by the fluid cap, and can be determined by using the EF chart for the specific fluid cap.

BASIC OPERATION

The basic XA nozzle assembly consists of a body, a spray set-up, and a "hardware assembly" that can provide shut-off and clean-out capabilities.

Non-Automatic Operation

The **XA00 Square Body** is the basic component of a non-automatic XA nozzle. Air and liquid feeds are located at opposite ends, perpendicular to the spray.

The **XA03 Body** has air and liquid feeds on one side, perpendicular to the spray axis.

The **XA05 Body** has air and liquid inlets located in-line with the spray. Hardware assemblies cannot be used with the XA05 body.

Hardware Assemblies for Non-**Automatic Operation**

A. Plug. The minimum option hardware assembly required for XA operation. Provides neither clean-out nor shut-off.

B. Shut-off. Turning the knurled knob will stop the flow of liquid to the nozzle. Should not be used to meter the flow of liquid.

C. Clean-out. Pressing the springloaded plunger will force a small dia-meter rod through the liquid orifice, cleaning any obstruction. Useful for intermittent spraying of a liquid that may dry in the orifice when not in use.

D. Clean-out/Shut-off. Combines functions of hardware assemblies B and C in one unit.



PR Air Cap







EF Air Cap



XW Air Cap










XA 01/02 Body with E or F Hardware

NEW ZEALAND spraynozzle.co.nz

sales@spraynozzle.co.nz 0800 NOZZLE | +64 (7) 839 6444





1800 NOZZLE | +61 (3) 9583 2368

AUTOMATIC OPERATION

For critical applications which require automatic, no-drip, or highspeed spray shut-off, the XA can be supplied with an air-cylinderoperated shut-off or clean-out/shutoff. These air cylinders provide virtually instantaneous liquid shut-off at rates of up to 180 cycles per minute. The air cylinders require a minimum of 5.5 bar to run that fast.

Bodies for Automatic Operation The XA01, XA02, XA10, and XA11 **Round Bodies** are rugged, highly reliable, and well-suited to the rigors of high-cycle automatic operation. They have been designed to simplify the feed piping required for installing automatic nozzles by providing a constant location for the air inlet piping. With their neat, professional appearance, they are particularly recommended for OEM applications.

The **XA01 Round Body** has one inlet for air and one for liquid. Because the air inlet supplies air for both cylinder movement and liquid atomization, spraying during startup and shut-off is not as crisp and precise as with the XA02. *The XA01* body cannot be used with atomizing air pressure under 2 bar.

The **XA02 Round Body** has two inlets for air and one inlet for liquid. One of the air inlets supplies the cylinder and the other supplies

atomizing air. The XA02 body must be used when the air cylinder operates at a different pressure from the atomizing air or where the atomizing air is supplied below 2 bar. *NOTE: The XA00 Square and XA03* Bodies used for non-automatic operation can also be used, with hardware assemblies E or F, for automatic operation. Special design features allow field upgrading to automatic operation.

The XA10 and XA11 Bodies have a built in air-operated cylinder. The integral cylinder provides a smaller profile for use where space is limited.

Hardware Assemblies for Automatic Operation

E. Air-Operated Shut-off. Removal of air pressure to the cylinder causes a spring-loaded poppet valve actuator to shut off liquid flow.

F. Air-Operated Clean-out/Shut-off. Operation similar to E, but includes a clean-out needle.

SOLENOID VALVES

Electrically operated solenoid valves can be used to control the operation of any XA nozzle. BETE can supply solenoid valves matched to your specific application.

Solenoids for Automatic XA Nozzles.

A 3-way, quick-exhaust solenoid valve is required to operate the E or F hardware assembly. The valve is

located in the line that supplies air to the cylinder, as close to the nozzle as possible. Independent control of the atomizing air of an XA02 or square body requires an additional 2-way solenoid valve.

Solenoids for Non-Automatic XA Nozzles.

Two-way solenoid valves can be used to stop and start the flow of air and liquid to any non-automatic XA nozzle.

FILTERS. REGULATORS AND STRAINERS

For optimum reliability, every XA nozzle should have a strainer and regulator in the liquid feed line and a filter and regulator in the air feed line. Every XA nozzle with a Siphon Feed Set-up should have a filter and regulator in the air line. The size and type of each of these components depends on the application, and can be determined by your BETE sales representative. BETE maintains an inventory of filters, strainers, and regulators that can be supplied with your XA nozzle to ensure reliable operation. These components can be purchased individually or in kit form.



Simple piping and robust design describe this multiple nozzle XA lance.



The XA06 manifold body can be fitted with up to five nozzle setups and is often used for humidification of large areas.



SPRAY EXTENSIONS

The spray set-up can be moved away from the nozzle body by using optional 152mm or 305mm extensions. These allow the spray to be moved closer to the target while keeping the nozzle body and associated piping at a distance.


MOUNTING HARDWARE

In many XA installations the nozzle is supported by the rigid metal pipe that supplies air or liquid. There are several components which can provide support for the XA Bodies when it isn't appropriate to suspend the nozzle from piping; for example, when the nozzle will spray through the wall of a tank or duct, or when the air and liquid will be supplied through flexible tubing. All XA bodies except the XA03 can be used with any of the mounting hardware described here.

Thin Wall 02 Adapter

Three-piece adapter used to support an XA nozzle with the body located outside a tank or duct having a relatively thin (less than 10mm) wall and the spray directed into the interior. To use this adapter, a 27mm diameter hole must be drilled through the wall. This adapter both secures the air cap and attaches the nozzle body to the tank wall.


BETE can fabricate XA nozzles



XA02 with Thin Wall 02 Adapter

Thick Wall 01 Adapter

Similar in design and function to the Thin Wall Adapter, but intended for use with tanks or ducts with walls that are thick enough (10mm or over) to be drilled and tapped for a 3/4" NPT thread.



XA02 with Thick Wall 01 Adapter

Mounting Bracket 03 Adapter

This bracket is used in combination with a Thin Wall Adapter to support an XA nozzle from a 13mm-diameter metal rod. The bracket allows flexibility in aiming the spray.

MATERIALS

Bodies, Fluid Caps, Air Caps, Hardware Assemblies, Mounting **Hardware**

The standard materials for the XA series are nickel-plated brass and 303 and 316 stainless steels. Other metals and plastics can be supplied on request. See page 12 for a complete material list.

Air Cylinders


The air cylinders used for XA hardware assemblies E and F have rods and cylinders made of stainless steel and end caps made of anodized aluminum. All metal parts in contact with the spray liquid are 316 stainless steel.

Seals

The standard material for XA gaskets is compressed fiber with a neoprene binder. For installations requiring FDA approval, SBR gaskets are available. Other elastomeric and metallic gasket materials can be supplied on

The standard material for O-rings in XA automatics is Viton®. Other materials available on request.







Spray lance (see pages 18, 19) with a right angle XA and quick-connect fittings

89

Spray Set-up Numbers PIPE **SPRAY** SET-UP SIZE SET-UP **FLUID** AIR BSP or NPT NO. CAP CAP EF 050 AC 1001 FC7 EF 100 AC 1003 EF 150 AC 1001 FC4 EF 200 EF 250 AC 1003 AC 1001 1/8 FC3 EF 300 EF 350 AC 1003 AC 1002 OR FC6 AC 1004 AC 1002 FLAT EF 400 EF 450 **EF** FAN 1/4 FC2 EF 500 AC 1004 (EXTERNAL EF 550 AC 1002 MIX) FC1 **EF 600** AC 1004 FC8 EF 650 AC 1005 EF 700 EF 750 FC9 FC5 AC 1005 AC 1005 1/2 EF 5050 FC501 AC 5001 SF 050 SF 100 FC3 FC6 AC1101 1/8 SIPHON AC1102 SF FLAT OR SF 150 FC2 AC1103 FAN 1/4 SF 200 FC2 AC1104 AC 1201 SR 050 FC7 SR 150 FC4 AC 1201 1/8 FC4 SR 200 AC 1202 SIPHON OR FC3 SR 250 AC 1202 SR **ROUND** FC1 FC5 1/4 SR 400 AC 1204 SR 450 AC 1205 SR 5050 FC501 AC5201 1/2 PF 050 FC4 AC 1301 PF 100 FC3 AC 1303 PF 150 FC3 AC 1301 1/8 PF 200 FC3 AC 1302 OR PF 250 PRESSURE FC2 AC 1304 PF PF 300 PF 350 FC1 AC 1304 FLAT AC 1305 FAN PF 400 FC5 AC 1306 FC501 AC5301 PF 5050 1/2 PF 5100 FC502 AC5302 **EXTRA** 1/8 OR 1/4 XW 050 FC8 AC 1401 XW WIDE-ANGLE XW 5050 FC502 AC 5401 ROUND PR 050 FC4 AC 1501 PR 100 FC4 AC 1502 1/8 PR 150 FC3 AC 1502 OR PR 200 FC2 AC 1503 1/4 PRESSURE PR PR 250 FC1 AC 1503 ROUND PR 300 FC5 AC 1504 FC501 FC502 PR 5050 AC 5501 1/2 PR 5100 AC 5502 AD 050 FC4 AC 1601 AD 100 FC2 FC2 AC 1603 1/8 AD 150 AC 1602

OR

1/4

1/2

1/8 OR 1/4

1/8

OR

1/4

AD 200

AD 250

AD 300

AD 5050

AD 5100

AD 5150

AD 5200

FF 050

ER 050

ER 150 ER 250

ER 350 ER 450

ER 550

ER 650 ER 750

ER 750 ER 850

FC1

FC1

FC5

FC501

FC 501

FC501

FC502


FC10

FC6 FC2 FC1


FC3 FC9 FC5


Dimensions with Hardware Options for XA00 Body, BSP or NPT

		Dimensions in (mm)			
Pipe	Hardware	W	X	Υ	Max. "Z"
Size	Option				
	Α				14.3
1/8	В				42.3
OR	С	22.2	42.9	49.2	63.5
1/4	D				77.0
	E				103
	F				103
1/2	Α	31.8	63.5	68.3	25.4
	1	I			



Overall Dimensions of XA Assemblies with XA00 Body (Shown with E or F Hardware)





AC 1603

AC 1604

AC 1605

AC 5601

AC 5602

AC 5603

AC5604

AC 1701

AC 1801

AC1802

AC1803

WIDE

ANGLE

ROUND

DEFLECTED

FLAT FAN

NARROW

ANGLE

ROUND

AD

FF

ER

SYSTEM SET-UPS AND **ACCESSORIES**

BETE carries a complete line of controls and accessories required for setting up a system using the XA Series nozzles.

Contact your BETE representative for details.

Pressure System Set-up

In a pressure-fed system, the liquid is supplied under pressure to either internal or external mix BETE XA Series nozzles.

Air and liquid regulators control the fluid delivery pressure, while the air filter and liquid strainer ensure that the supplied fluids are of high quality.

Operational control is maintained by manual or solenoid valves used in conjunction with the various hardware assemblies.

Siphon System Set-up


In a siphon-fed system, the liquid is supplied by either a siphon or gravity feed.

An air regulator controls the air delivery pressure, while the air filter ensures that the compressed air is of high quality.


Operational control is maintained by manual or solenoid valves used in conjunction with the various hardware assemblies.

When used as a gravity feed set-up, a positive liquid shutoff capability should be provided.

Filters, regulators, and strainers matched to your XA application are available from stock.



PRESSURE SYSTEM



SIPHON SYSTEM

1800 NOZZLE | +61 (3) 9583 2368